


TOP AND CONSOLE PARTS

For Models: GGQ8811PW0, GGQ8811PG0, GGQ8811PL0 (White/Grey) (Biscuit/Gold) (Pewter)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Wiring Diagram Guide, Use & Care Sheet.	9 10 12 13	3390646	Bracket, Control Screw, 8–18 x 5/16 Screw, Console Switch,	27 28		Connector Connector, 3–Position (Gas Valve)
		Cycle Feature Instructions, Installation	14 15	3391018	Temperature Tie, Cable (Push–Mount) Knob, Control (3)	29 30 31	3390537 694419	
Follo	wing May	y Be Purchased	'0	8544937	Grey	31		(Includes
_	D-IT-YOU PAIR MA	_	16 17 18	717252	Connector, Timer Receptacle, 2–Way Connector,	32	8546001 8546002 3405154	Gold
	677818	Manual, Do-It- Yourself Repair (Dryer)	19 20	8299951	2–Position (Gas Valve) Harness, Wiring Timer Knob	33		Wrinkle Shield Knob, Push-To-Start
2	8317305	Panel, Rear Console	20	8544957	Assembly	35	8544941 8544942	Biscuit
3 4	3406725		04	8544958	Biscuit	36	8317340	
-		(8-18 x 7/32)	21 22	8318255	Screw, 8–18 x 3/8 Strap, Console	37	3401144	Terminal Block Connector
5	3398094	Push-To-Start	23 24		Nut, Push-In (2) Top	38		(PTS Relay) Screw, 8-18 x 3/8
6 7		Connector, Edge Connector		8535848 8535849	Biscuit	40	3347243	Connector, 6–Circuit
8	8271359 8271362	Biscuit	25 26	8546092 3405152	Switch, End Of Cycle Cap, End (L.H.)	41 42 43 44	8536939 8533990	Clip, Harness Spring Clip Medallion Terminal
	3956023	Gley		8271365 8271368 3956024	Biscuit			

CABINET PARTS



CABINET PARTS

For Models: GGQ8811PW0, GGQ8811PG0, GGQ8811PL0 (White/Grey) (Biscuit/Gold) (Pewter)

			•	,,	(Bisoult Cold) (i c	-		
Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
	007770	0 0 00 7/0						
1		Screw, 6-20 x 7/8	18	233520	Washer, Thrust	49		Door, Front
2		Bracket, Burner	19	297092	Clip (2)		8521938	
3	8281212	Screw, 8-18 x 3/8	20	690997	Tri Rìng		8521939	
4		Plate, Cover	21		Hinge, Door (R.H.)		8521936	Grey
5	3394881	Switch, Broken			Hinge, Door (L.H.)	51		Upper Front Panel
_		Belt	22		Spring, Door (2)		697227	
6	344020	Cord, Power	23		Lever, Snap		3977761	
7		Cabinet			Switch		3979198	
	8310656		24	3394081	Wire, Belt Switch	52		Strike, Door
	8310659		25		4" – 90° Elbow	57		Seal, Door
_	8528155		26	3393657	Restrainer, Belt	58	690081	Catch, Door
8		Foot, Dryer	27		Motor, Assembly			Assembly
	279810	Foot – Optional	-		60 HZ.	60		Handle, Door
		(Extended Length	28	3395534	Exhaust Pipe		3979726	Sage
		Package Of 2)			(Short)		3979727	
		(Not Included)	29	3389729	Pulley 60 HZ.	61		Toe, Panel
9		Clamp, Motor (2)	30		Belt, Drive			(Includes
10		Spring, Idler	31		Bumper			Illus. 31)
11	3389420	Retainer, Idler	32		Bracket, Motor		697215	
12		Plug, Multivent	33		Exhaust Pipe		3977764	
	697750				(Long)		3979197	Grey
	3388311		35	98129	Screw,			
	3979261				6-20 x 1 3/8			
13		Pulley Assembly	36	693995	Screw, 8-18 x 3/8	Opt	ional Pa	rts Not Included
14		Screw, 10-16 x 1/2	39		Idler Bracket	l —		
15		Screw, Ground	40	3357011	Screw, 10-16 x 1/2		Dryer	Exhaust Kit
16	3398948	Wire, Jumper	41		Door Switch	,_	-	
		(Broken Belt			Assembly	(F0	r Side &	Bottom Venting)
47	0005500	Switch)	44	3387242	Seal, Front Panel			<u> </u>
17	3395532	Exhaust Pipe	46		Retainer			140.5
		& Bracket	47		Door, Rear	62	279818	
			48	694091	Screw, 8-18 x 3/8		279925	
			l			I	279969	Grey

OPTIONAL PARTS (NOT INCLUDED)

Illus. Part No. No.	DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
ACCESSOR	Y PARTS	PAINT, TOUCH-UP (1/2oz.)	PAINT, BULK (1 qt.)
8522199	7 Kit, Dryer Repair 1 Dry Rack 2 Kit, Dryer Vent Testing 1 Kit, Hold-Down (Gas Dryer Mobile Home Installation)	72017 White 4392899 Biscuit 4396174 Pewter PAINT, PRESSURIZED SPRAY (12 oz.) 350930 White 4392901 Biscuit 4396175 Pewter 350938 Primer, Gray	799344 White (Uncut) 4392900 Biscuit(Uncut)

BULKHEAD PARTS

BULKHEAD PARTS

For Models: GGQ8811PW0, GGQ8811PG0, GGQ8811PL0 (White/Grey) (Biscuit/Gold) (Pewter)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread	16	3387709	Nut, 3/8-16 (L.H.)	38	3977373	Bracket,
2	3390647	Screw, 8-18 x 1/2	17	8520836	Bulkhead, Rear			Drum Light
3	90767	Screw, 8-18 x 3/8	18	3387459	Washer, Support	42	8318268	Thermostat,
4	3394986	Spring, Lint	19	3399509	Shaft, L.H. Thread			Internal Bias
		Screen Door	20		Ring, Tri	43	3403140	Thermostat,
5		Air Duct Assembly	21	8536973	Roller, Support			High-Limit 205°F
6	697813	Seal, Outlet	22	3392258	Wire, Ground			(96°C)
		Housing			(Sensor)	44	8544362	Housing, Blower
7	697814	Seal, Drum Front	23	3394985	Outlet Housing	45	8066168	Lint Duct Assembly
8 9		Nut,3/8 x 16(R.H.)			Assembly	46	8066047	Funnel, Burner
9	8066086	Drum Hole	24		Screw, 8-18 x 1/2	48	338906	Sensor, Radiant
		Plug	25	8318215	Complete Drum	51		Screw, 10-16 x 1
10		Screw, 8-18 x 5/16			Assembly	53		Baffle, Drum
11		Socket Assembly	26		Screw, 11-16 x 3/4	54	697557	Bulkhead, Front
12	3388229		27		Seal, Drum	58	8299979	Grill, Outlet
13	695240	Screw, 8-18 x 1/2	34		Electrode, Sensor	59	3392519	Thermal Fuse
14	3394984	Door, Lint	35	3402841	Lens, Drum	60	697770	Seal, Cover Plate
		Screen			Light	64		Lint, Screen
15	8318486	Exhaust Pipe	36		Bulb, Light	65	487909	Screw, 8-15 x 1/2
			37	697772	Wheel, Blower			

8318276 BURNER ASSEMBLY

For Models: GGQ8811PW0, GGQ8811PG0, GGQ8811PL0 (White/Grey) (Biscuit/Gold) (Pewter)

USE WITH TYPE 1 - NATURAL AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

BA-149

- 8

8318276 BURNER ASSEMBLY

For Models: GGQ8811PW0, GGQ8811PG0, GGQ8811PL0 (White/Grey) (Biscuit/Gold) (Pewter)

USE WITH TYPE 1 – NATURAL AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

1 8318276 Burner Assembly 60 Hz. (Type 1) (White Rodgers) 2 688617 Tube, Burner 3 694298 Bracket, Ignitor 4 686590 Ignitor 5 3393909 Screw & Washer (8–32 x 7/8) 6 343641 Screw, 10–16 x 1/2 7 3389871 Base, Burner 8 3387057 Screw, 8–18 x 3/8 Orifice, Burner 234826 Type 1 229742 Type 4 (Butane) 234868 Type 4 (Propane) 10 8318281 Valve, Gas 60 Hz. (Complete)	Illus. No.	Part No.	DESCRIPTION
2 688617 Tube, Burner 3 694298 Bracket, Ignitor 4 686590 Ignitor 5 3393909 Screw & Washer (8–32 x 7/8) 6 343641 Screw, 10–16 x 1/2 7 3389871 Base, Burner 8 3387057 Screw, 8–18 x 3/8 9 Orifice, Burner 234826 Type 1 229742 Type 4 (Butane) 234868 Type 4 (Propane) 10 8318281 Valve, Gas 60 Hz. (Complete)	1	8318276	60 Hz. (Type 1)
6 343641 Screw, 10–16 x 1/2 7 3389871 Base, Burner 8 3387057 Screw, 8–18 x 3/8 9 Orifice, Burner 234826 Type 1 229742 Type 4 (Butane) 234868 Type 4 (Propane) 10 8318281 Valve, Gas 60 Hz. (Complete)		694298 686590	Tube, Burner Bracket, Ignitor Ignitor Screw & Washer
9 Orifice, Burner 234826 Type 1 229742 Type 4 (Butane) 234868 Type 4 (Propane) 10 8318281 Valve, Gas 60 Hz. (Complete)	7	3389871	Screw, 10–16 x 1/2 Base, Burner Screw,
10 8318281 Valve, Gas 60 Hz. (Complete)	9	229742	Orifice, Burner Type 1 Type 4 (Butane)
(Includes Pipe & Illus. #7).	10		Valve, Gas 60 Hz. (Complete) (Includes Pipe &
11 694421 Screw, 8–32 x 1/2 (2)	11	694421	Screw,
12 694538 Bracket, Coil 13 694540 Coil, 60 Hz. (2 Terminal) (Main)			Bracket, Coil Coil, 60 Hz. (2 Terminal)
14 694539 Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)	14	694539	Coil, 60 Hz. (Split) (3 Terminal)
15 694424 Leak, Limiter 16 694423 Screw, Regulator Adjustment			Leak, Limiter Screw, Regulator
17 694422 Spring, Regulator 18 3390647 Screw, 8–18 x 1/2 20 239822 Plug, Pipe 25 3387561 Clamp, Pipe 26 3389889 Bracket, Support	18 20 25	3390647 239822 3387561	Spring, Regulator Screw, 8–18 x 1/2 Plug, Pipe Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit (Type (1) to Type (4) LPG).

BA-149